



MALTA DYNAMICS

***Pygmy Hog, Warthog,
Hybrid, & Razorback SRL
Instruction Manual***



Pygmy Hog®, Warthog®, and Razorback™ SRL INSTRUCTION MANUAL

These instructions apply to the following model(s):

- C7102 - 6' Pygmy Hog® Single SRL with Snap Hook Class A**
- C7103 - 6' Pygmy Hog® Single SRL with Peri Form Hook Class A**
- C7104 - 6' Pygmy Hog® Single SRL with Rebar Hook Class A**
- C7201 - 11' Pygmy Hog® Single SRL with Snap Hook Class B**
- C7202 - 11' Pygmy Hog® Single SRL with Peri Form Hook Class B**
- C7203 - 11' Pygmy Hog® Single SRL with Rebar Hook Class B**
- C7002 - 50' Warthog® SRL with Snap Hook Class B**
- C8000 - Razorback™ Heavy Duty 20' SRL Class B**
- C8001 - Razorback™ Heavy Duty 30' SRL Class B**
- C9000 - 20' Warthog® SRL with Snap Hook Class A & B**
- C9001 - 30' Warthog® SRL with Snap Hook Class A & B**

Manual Revision Code: **MD-PHRSRLUIM 11-23-18**

A copy of this manual must be available to users at all times. Visit www.MaltaDynamics.com for the latest user instruction manual based upon date of manufacture.



TABLE OF CONTENTS

Under Penalty of Law -----	4
Materials and Construction -----	4
Purpose -----	5
Instructions for Use -----	5
Limitations for Use -----	7
Connector Compatibility Limitations -----	8
Connecting Component Limitations -----	9
Performance -----	9
Training -----	14
Inspection -----	14
Cleaning and Maintenance -----	16
Product Labels -----	17
Single & Twin Connections for C7102, C7103, C7104, C7201, C7202, & C7203 -----	25
About the Pygmy Hog SRD with C1004 -----	25
About the Pygmy Hog SRD with C1005 -----	26
Clearance and Swing Falls -----	27
Compatibility of Connectors -----	28
Installation and Use of the Self-Retracting Device -----	28
Single Housing End Attached To The Full Body Harness -----	29
Single Housing End Attached to the Anchorage -----	30
Twin-leg SRDs -----	31
Install the C1004 -----	32
Install the C1005 -----	34
Twin-leg SRD Work Zone Transition -----	36
Inspection Log -----	37
Warranty -----	38



UNDER PENALTY OF LAW

This manual must be read and understood in its entirety and used as part of your fall protection training program as required by OSHA 1926 and State and local regulatory agencies. This instruction manual is intended to meet industry standards required by and ANSI Z359.14-2014 and should be used as part of an Employee Fall Safety training program as required by OSHA. User must read and fully understand the limitations and proper use of the equipment, and be properly trained by employer prior to use per OSHA 29 CFR 1910.66, 29 CFR 1926.503, and applicable local standards. NOTE: This *User Instruction Manual* is not to be removed except by the user of this equipment. Current *User Instruction Manuals* must always be available to the user. Read and understand these instructions before using equipment. *Do not discard these instructions.*

WARNING

Misuse or failure to follow warnings, instructions and limitations on the use of this equipment may result in serious personal injury or death. For further instructions about proper use, refer to supervisor or contact Malta Dynamics at 1-800-494-1840.

MATERIALS AND CONSTRUCTION

Webbing Materials for C7102, C7103, C7104, C7201, C7202 & C7203

- Constructed with UHMWPE with polyester (.770" width; .063" thickness); breaking strength > 4500 lbs tensile strength

Cable Materials for C7002, C8000, C8001, C9000, & C9001

- 7X19 Galvanized Steel (3/16" diameter)

Connector Materials

- Stainless Steel and Alloy Steel

Housing Materials

- Aluminum for C8000 & C8001
- High-Impact Resistant Polymer for C7102, C7103, C7104, C7201, C7202, C7203, C7002, C9000, & C9001

PURPOSE

Malta Dynamics Self-Retracting Lifelines are devices used to safely expand the working area where a harness with a six-foot lanyard is not adequate. A Self-Retracting Device (SRD) such as a self-retracting lifeline, is designed to reduce the shock load to the body of a worker by limiting the distance of a fall. The SRD allows complete freedom of movement. An SRD is one component of a Personal Fall Arrest System (PFAS). PFAS normally include a full body harness, anchorage connector (such as a carabiner and an SRD.)

The Self-Retracting Lifeline (SRL) may be used in a stationary or mobile manner. As a stationary device, the SRL should be mounted to an approved, fixed anchorage connector overhead. The SRL extends as the user moves away from the anchor point, and retracts as the user moves back toward the anchorage point. An SRL used in a mobile manner should travel on a steel cable, rope or fixed rail, traveling from one anchorage connector to another.

Self-Retracting Lifelines may include a swivel eye anchorage, self-locking swivel snap hook or universal rebar hook with impact indicator and 3/16" wire cable or webbing, carabiner and tag line.

INSTRUCTIONS FOR USE



WARNING

SRLs are designed for overhead use ONLY.



WARNING

Do not alter or intentionally misuse this equipment.

- Personal Fall Arrest System (PFAS) MUST limit maximum arrest forces to 1800 lbs. (8kN) or less.
- Employees shall be trained in accordance with the requirements of OSHA 29 CFR 1910.66 in the safe use of the system and its components before using a PFAS.
- Inspect all Personal Fall Arrest System equipment for wear, damage, and other deterioration prior to each use. Remove defective equipment from service immediately.
- Thoroughly evaluate and plan all elements of Fall Protection System(s) before using this equipment. Make sure that your Personal Fall




Arrest System is appropriate for your needs and facility. Calculate fall clearance and swing fall clearance. The amount of clearance required is dependent on the type of connecting subsystem, the anchorage location, and other factors. When calculating distance, be sure to consider:

- Deceleration Distance
- Movement of harness attachment (D-ring)
- Free Fall Distance
- Height of the worker (how tall is the worker?)
- Elevation of Anchorage Connector
- Connecting Subsystems length
- D-ring connector length
- Length of Full Body Harness stretch
- Swing

falls

- Swing falls occur when the anchorage point is not directly above the point where a fall occurs. The force of striking an object in a swing fall may cause serious injury or death. Minimize potential for swing falls by working as close to the anchorage point as possible. Do not permit a swing fall if injury could occur. Swing falls significantly increase the amount of clearance required. **See Illustration 1.**

Illustration 1: Examples of Swing Fall Hazards



- Users must have a written rescue plan and the means to implement it. This plan must provide prompt employee rescue or assure that employees have the ability to rescue themselves in the event of a fall.
- Store this equipment in a cool, dry, and clean environment that is out of direct light when not in use to prevent UV degradation.
- This equipment must be removed from service immediately if a fall is incurred.

LIMITATIONS FOR USE

WARNING

Do not use this equipment if you are unable to tolerate the impact of a fall arrest. Age and fitness can seriously affect your ability to withstand a fall. Consult with a physician if in doubt. Minors, pregnant women, and anyone with a history of back and/or neck problems must not use this equipment.

WARNING

Use caution when employing this equipment around machines, electrical hazards, chemical hazards and sharp edges or abrasive surfaces, as contact may cause equipment failure, personal injury, or death.

- Do not allow the line constituent to retract into the unit in an uncontrolled manner.
- Malta Dynamics self-retracting lanyards must be used with a full body harness and shall only be used as a personal fall arrest system that limits the maximum free fall distance to 2 feet (0.6 m).
- Use only with compatible components of subsystems. Substitutions or replacements made with non-approved components or subsystems may jeopardize compatibility of equipment and may affect the safety and reliability of the complete system.
- Not all fall protection components are rated for the same user weight capacity. Users must be within each component capacity range.
- Self-Retracting Lifelines are designed for a single user with combined weight - including clothing, tools, etc. - within ANSI rated weight capacity range of 130 lbs. to 310 lbs. and maximum OSHA capacity of 420 lbs.
- This equipment is designed to be used in temperatures ranging from -40°F to +130°F (-40°C - +54°C).
- Use only with structures capable of supporting static loads required for Personal Fall Arrest Systems (PFAS). Anchorages used for PFAS must be capable of sustaining static loads in the direction permitted by the PFAS of at least: 3,600 lbs. with certification of a qualified person; or 5,000 lbs. without certification. When more than one PFAS is attached to an anchorage, the strengths stated above must be met independently at and for each anchorage location.



- Do not expose this equipment to chemicals or harsh solutions that may have a harmful effect.
- User must not use or install equipment before receiving proper training from a Competent Person, as defined by OSHA 29 CFR 1926.32(f).
- Only Malta Dynamics shall make repairs or alterations to the equipment.
- All synthetic material must be protected from slag, hot sparks, open flames, or other heat sources. The use of heat resistant materials is recommended in these applications.

CONNECTOR COMPATIBILITY LIMITATIONS

Malta Dynamics equipment must be coupled only to compatible connectors that are suitable to your application. Ensure all connections are compatible in size, shape and strength. Ensure all connectors are fully closed and locked. OSHA 29 CFR 1926.502 prohibits the use of snap hooks to engage to objects unless the following requirements are met:

- Snap hook must be a locking type snap hook.
- Snap hook must be explicitly designed for such a connection. “Designed for” means that the manufacturer of the snap hook specifically created the snap hook to be used to connect to the equipment in question.


Use of a non-locking snap hook can result in rollout (a process by which a snap hook or carabiner unintentionally disengages from another connector or object to which it is coupled. ANSI Z359.0- 2007). Malta Dynamics connectors (snap hooks and carabiners) are designed to be used only as specified in each product’s user’s instructions.

Avoid the following types of connections:

- Connection of two (or more) snap hooks or carabiners to one D-ring.
- Connection of a snap hook back to its integral lanyard.
- Direct connection of a snap hook to horizontal lifeline.
- Connection in a manner that results in a load on the gate. NOTE: *Large throat opening snap hooks should not be connected to standard size D-rings or similar objects, as such use will result in a load on the gate if the hook or D-ring twists or rotates. Large throat snap hooks are designed for use on structural elements such as rebar or cross members that are not shaped in such a way that they may capture the gate of the hook.*
- False engagement connections, where protruding features of the snap hook or carabiner may catch on the anchor and seem to be fully engaged to the anchor point. Always confirm engagement.
- Connection to snap hooks or carabiners.
- Direct connection to webbing lanyard, webbing loop, rope lanyard or tie-back (unless the manufacturer’s instructions for both the lanyard and connector specifically allow such a connection).

- Connection of a snap hook to a D-ring, rebar, or other connection point of improper dimensions in relation to the snap hook dimensions or configurations that could cause the snap hook keeper to be depressed by a turning motion of the snap hook, or such that snap hook or carabiner will not fully close and lock, or that roll-out could occur.

Illustration 2 depicts examples of inappropriate connections:



CONNECTING COMPONENT LIMITATIONS

- A Competent Person must ensure the compatibility of all connections and that of the system.
- Do not use the system if any connector does not lock or if any other component in the system does not operate properly.
- Allow sufficient safe clearance in the event of a Free Fall.
- System must be rigged to limit the total Free Fall Distance according to the type of system, and in compliance with ANSI and OSHA directives.
- Do not use if any part of the system appears to be damaged.
- Do not use a body belt for fall arrest applications.



PERFORMANCE

Class B SRLs must have an average arresting force of 900 lbs. (4kN) and total fall arrest distance of 54 inches when dynamically tested in accordance with the requirements of the ANSI.14:2014 standard. - Self-Retracting Device - Class B

Class A Self-Retracting Lifelines must have an average arresting force of 1350 lbs. (4kN) and total fall arrest distance of 24 inches when dynamically tested in accordance with the requirements of the ANSI.14:2014 standard. - Self-Retracting Device - Class A

Model/ Part #	Description (Materials & Size)	Lifeline Length	Max Arrest Distance	ANSI® Z359.14 Class
C7102	Impact Resistant Polymer Housing, UHMWPE with polyester Webbing, Steel Snap Hook	6ft.	24 in.	A
C7103	Impact Resistant Polymer Housing, UHMWPE with polyester Webbing, Universal Steel Peri Form Hook	6ft.	24 in.	A
C7104	Impact Resistant Polymer Housing, UHMWPE with polyester Webbing, Steel Rebar Hook	6ft.	24 in.	A
C7201	Impact Resistant Polymer Housing, UHMWPE with polyester Webbing, Steel Snap Hook	11ft.	54 in.	B
C7202	Impact Resistant Polymer Housing, UHMWPE with polyester Webbing, Universal Steel Peri Form Hook	11ft.	54 in.	B
C7203	Impact Resistant Polymer Housing, UHMWPE with polyester Webbing, Steel Rebar Hook	11ft.	54 in.	B
C7002	Impact Resistant Polymer Housing, Galvanized Steel Cable, Steel Snap Hook	50ft.	54 in.	B
C8000	Die Cast Aluminum Housing, Galvanized Steel Cable, Steel Snap Hook	20ft.	54 in.	B
C8001	Die Cast Aluminum Housing, Galvanized Steel Cable, Steel Snap Hook	30ft.	54 in.	B
C9000	Impact Resistant Polymer Housing, Galvanized Steel Cable, Steel Snap Hook	20ft.	24 in.	A & B
C9001	Impact Resistant Polymer Housing, Galvanized Steel Cable, Steel Snap Hook	30ft.	24 in.	A & B

Applicable Standards:

Refer to national standards, including ANSI Z359.1, and local, state and federal (OSHA 1910.66, appendix C, 1926.500) requirements for more information on personal fall arrest systems and associated components.

Capacity:

Malta Dynamics Self-Retracting Lifelines are designed for use by an individual person with a combined weight (worker, clothing, tools, etc.) of 130 lbs. minimum to no more than 310 lbs. maximum for ANSI rated capacity. OSHA max capacity is 420 lbs. No more than one person may be connected at one time.

Anchorage Strength:

In accordance with ANSI Z359.1, any anchorage selected for **Personal Fall Arrest Systems must meet all** anchorage strength requirements. Anchorages used for PFAS must be capable of sustaining static loads in the direction permitted by the PFAS of at least: 3,600 lbs. with certification of a qualified person; or 5,000 lbs. without certification. When more than one PFAS is attached to an anchorage, the strengths stated above must be met independently at and for each anchorage location. Avoid potential swing fall hazards and obstructions.

Free Fall:


Maximum free fall distance allowed for use in a Personal Fall Arrest System is 2 ft. Do not work above the anchorage level to avoid increased Free Fall Distance. Avoid slack in the line and do not lengthen the Self-Retracting Lifeline by connecting a lanyard or other snap hook directly to the retractable. Do not use this device at or below the level of your feet. Using it thus will increase your free fall distance beyond the allowable limits set by OSHA and exceed the capabilities of this device to safely arrest a fall.

Fall Arrest Forces:

Personal Fall Arrest System (PFAS) MUST limit maximum arrest forces to 1800 lbs. (8kN) or less.

Swing Falls:

Self-Retracting Lifelines should be used in a vertical position only. Minimize swing fall by working as directly below the anchorage point as possible. Worker movement should remain within 30 degrees maximum deflection of the lifeline from the vertical line directly below the anchorage point. **(Illustration 3)**. Do not permit a swing fall if injury could occur.



Sharp Edges:

Avoid working where sharp edges may contact lifeline. Provide sufficient protective padding where avoiding sharp edges is not possible. Malta Dynamics energy absorbing device may be required to reduce impact force on the entire system.

Corrosive Environment:

Extensive exposure to environments where corrosion may occur will damage metal parts in the Self-Retracting Lifeline. Use caution when working around corrosive compounds such as ammonia, sewage, fertilizers, sea water or other corrosives.

Chemical Hazard, High Heat and Severe Cold:

Use extreme caution in environments containing acid or caustic chemicals, particularly at elevated temperatures, as chemical damage that can impair the functionality of the Self-Retracting Lifeline (SRL) is difficult to detect. Periodic replacement of the SRL is recommended to ensure safety. Do not use SRL in high temperature environments. Do not use SRL in severe cold. Protect SRL if used near welding, metal cutting, or similar activities. Hot sparks and slag can damage SRL and impair functionality.

Electrical Hazards:

Use extreme caution to avoid contact with high voltage power lines. Both web and wire cable model Self-Retracting Lifelines may conduct electricity. Moisture absorbed by the lifeline can provide a path for electrical current to flow, resulting in potential electrical shock.

Locking Speed:

Use extreme caution when working on low-pitched roofs where a worker may slide, rather than fall. A clear path is required to ensure positive locking of the Self-Retracting Lifeline.

General Adverse Environment Conditions:

User must be aware of working conditions and environment during all aspects of use. Adverse working conditions and environment require additional attention and extreme caution. Adverse working conditions and environments include but are not limited to areas involving mortar/cement/concrete, dust/demolition, caustic/corrosive materials, falling objects, gypsum, slurry, petroleum based liquids, extreme wet conditions, mud, or metal/plastic shavings. User is to use extreme caution of materials that may adhere to or strike the SRL line constituent. Material that adheres to line constituent may damage parts within the Self-Retracting Lifeline and may lead to serious injury or death. Falling objects that strike the SRL line constituent may cause a fall to occur in addition to weakening or breaking the SRL and anchorage which will may result in serious injury or death.

Fall Clearance:

Consider the following when calculating fall clearance. Clearance required is dependent on the following factors:

- Elevation of Anchorage
- Connecting Subsystem Length
- Deceleration Distance
- Free Fall Distance
- Worker Height
- D-ring / connector length
- Movement of Harness Attachment Element
- Length of Full Body Harness (FBH) Stretch
- Working Level

See Illustration 4.

Illustration 4: Fall Clearance Considerations

A. Connecting Subsystems (Energy Absorbing Lanyard shown) Length + Movement of Harness Attachment + Length of FBH Stretch

B. Working Level (thickness)


C. Worker Height + Connector Length

D. Free Fall - 6 ft. Max. (per ANSI Z359.1)

E. Deceleration Distance

F. Total Fall Distance: Sum of A through E

G. Lower Level or Obstruction



If there is a risk of a fall or if the only anchorage point is below the attachment points on the harness, it is essential to use a lanyard provided with an energy absorber. Before using a shock absorbing lanyard, ensure that there is sufficient fall clearance below the user to prevent any collision with the structure or the ground.

WARNING

If a Self-Retracting Lanyard is used with an extended D-ring, cross arm anchorage connector, other anchorage connector, or horizontal lifeline, the additional length provided by these components must be taken into consideration during the clearance calculation process.




Calculating Total Fall Distances:

Total Fall Clearance below worker is calculated from Anchorage Connection. Free Fall Distance + Working Level + Energy Absorber + Deceleration Distance + Worker Height + Connector Length + Safety Factor. Ensure that the total fall distance is clear of obstructions and equipment. Avoid potential contact with a lower level. See **Illustration 5**.

Horizontal Systems and Tripods:

Ensure the support structure and/or horizontal system components are compatible if using Self-Retracting Lifeline in conjunction with a horizontal system, tripod or davit arm. Horizontal systems must be designed and installed under the supervision of a qualified engineer.

Illustration 5: Calculating Total Fall Distance



TRAINING

Employers are responsible for providing training to any employee who may be exposed to fall hazards in order to enable the employee to recognize and reduce fall hazards. Training must be conducted by a Competent or Qualified Person. Trainer and trainees must not be exposed to fall hazards during the training course.

INSPECTION

Record all observations and results of each inspection in your Hog Tracker account or inspection log. **If inspection reveals any defect, inadequate maintenance, or unsafe condition, remove Self Retracting Lifeline from service immediately.**

After a Fall:

Remove Self-Retracting Lifeline (SRL) from service immediately after a fall has occurred. Inspect the impact indicator on the snap hook of the SRL; look for an exposed red color band. Do not reset the impact indicator. SRL with a webbed lifeline requires additional inspection of the shock pack, looking for deformation, elongation or other signs of the shock pack being torn or deployed.

Self-Retracting Lifeline (SRL) must be inspected a minimum of twice per year (every six months) by an OSHA-defined “Competent person” other than the user. Local, state, governmental, and jurisdictional agencies may require the user to conduct more frequent or mandatory inspections. If the SRL is exposed to extreme or severe conditions, more frequent formal inspections may be required. Record the results of each formal inspection in your Hog Tracker account or inspection log.

User Inspection

Self-Retracting Lifeline (SRL) should be inspected by the user before each use, using the inspection procedures below (Illustration 6). In addition, unit should be fully examined and inspected to ensure:

- Markings are legible
- Components are free from corrosion, bending, cracks, dents or deformation
- SRL is clean and free of dirt, oil, mold, mildew and contaminants

Inspection Procedure

Step 1: Inspect for loose screws and bent or damaged parts.

Step 2: Inspect housing for distortion, cracks or other damage. Ensure swivel eye is not damaged or distorted. Swivel eye must turn freely.

Step 3: Ensure lifeline extends and retracts fully without hesitation or creation of slack in the line.

Step 4: Ensure device engages (locks up) when lifeline is jerked (tugged) sharply.

Step 5: Inspect wire cable lifelines for cuts, kinks, broken wires, bird-caging corrosion, welding splatter, chemical damage or severe abrasion. Check all thimbles and other areas for excessive wear, including cracks or separation of metal components.

Step 6: Inspect webbed lifelines for frayed strands, broken webbing, burns, cuts and abrasions. Look for heat damage, paint build-up, corrosion and chemical damage indicated by discoloration.

Step 7: Inspect all snap hooks and connectors for damage; ensure secure, locking engagement.



Cable Inspection Considerations:

User must be aware of the potential for damage or deterioration that may occur while in use.

Crushing: Cable may get crushed or bent while in general use, resulting in unsafe condition for use.

Cutting: Movement over sharp edges or other objects while cable in under tension can damage or break strands, resulting in an unsafe condition for use.

Abrasion: Normal wear can result in abrasion. Pay particular attention to outer strands, which are most susceptible to abrasion. Extreme abrasion results in an unsafe condition for use.

Kinking: Deformation in the cable causes the lifeline to appear bent or kinked, and results in an unsafe condition for use.

Corrosion Damage: Use extreme caution to avoid potential damage when using a Self-Retracting Lifeline in an environment where corrosive compounds, welding or high heat may exist. Corrosion damage can cause cable to crack. Working in a corrosive environment requires increased inspection frequency to ensure corrosive damage does not impact the performance of the SRL.

Arc or Heat Damage: Welding or high heat may fuse cable wires and change the strength characteristics of the wire and cable as a whole. Periodically examine the SRL if it must be used in these types of environments.

CLEANING AND MAINTENANCE

Cleaning


Wipe off all surface dirt. Store in clean, dry area, away from heat and areas where chemical vapors may exist. Avoid storing in direct light to prevent UV degradation.

Maintenance

Do not attempt to disassemble or repair. Only Malta Dynamics or entities authorized in writing by Malta Dynamics shall make repairs, authorized maintenance or alterations to the equipment.

PRODUCT LABELS


The following labeling is affixed to product and must not be removed:




C7102





Front




Back




C7103



Front




Back





C7104



Front



Back



C7201



Front



Back



C7202



Front



Back



WARNING: ⓘ

Fully read and understand all manufacturer's instructions, which are provided and packaged with this equipment at time of shipment. **DO NOT ATTEMPT TO SELF SERVICE OR REPAIR THIS EQUIPMENT! DO NOT REMOVE THIS LABEL!** Use, maintain and inspect this equipment in accordance with manufacturer's instruction manual and labels included with this device at time of shipment.

OSHA COMPLIANT ANSI Z359.14-2014

MALTA DYNAMICS
800-494-1840 | MaltaDynamics.com
210 13th Street | Malta, OH 43758

HOG TRACKER
13.56 MHz Smart Tag, Scan tag for product updates & more!

WARNING: Test locking & retraction before each use.

WARNING: Inspect webbing before each use.

30°max Avoid contact with sharp edges & abrasive surfaces.

2 ft. Free Fall Limit

WORKING CAPACITIES: ANSI: 130-310 lbs. OSHA: 130-420 lbs.

WARNING: Inspect load restraint before each use.

ⓘ Follow instructions for proper SRL attachment.

SUITABLE FOR HORIZONTAL LIFELINE

TEMPERATURE: 54°C / 130°F to -40°C / -100°F

C7203



Front



Back



WARNING: ⓘ

Fully read and understand all manufacturer's instructions, which are provided and packaged with this equipment at time of shipment. **DO NOT ATTEMPT TO SELF SERVICE OR REPAIR THIS EQUIPMENT! DO NOT REMOVE THIS LABEL!** Use, maintain and inspect this equipment in accordance with manufacturer's instruction manual and labels included with this device at time of shipment.

OSHA COMPLIANT ANSI Z359.14-2014

MALTA DYNAMICS
800-494-1840 | MaltaDynamics.com
210 13th Street | Malta, OH 43758

HOG TRACKER
13.56 MHz Smart Tag, Scan tag for product updates & more!

WARNING: Test locking & retraction before each use.

WARNING: Inspect webbing before each use.

30°max Avoid contact with sharp edges & abrasive surfaces.

2 ft. Free Fall Limit

WORKING CAPACITIES: ANSI: 130-310 lbs. OSHA: 130-420 lbs.

WARNING: Inspect load restraint before each use.

ⓘ Follow instructions for proper SRL attachment.

SUITABLE FOR HORIZONTAL LIFELINE

TEMPERATURE: 54°C / 130°F to -40°C / -100°F



C9000



WARNING:

Fully read and understand all manufacturer's instructions, which are provided and packaged with this equipment at time of shipment. **DO NOT ATTEMPT TO SELF SERVICE OR REPAIR THIS EQUIPMENT. DO NOT REMOVE THIS LABEL.** Use, maintain and inspect this equipment in accordance with manufacturer's instruction manual and labels included with this device at time of shipment.

Class A Max Arresting Distance: 24in. Average Arresting Force: 1350lbs	This SRL meets BOTH Classes simultaneously!	Class B Max Arresting Distance: 54in. Average Arresting Force: 1350lbs
--	---	--

Malta Dynamics Hybrid hog has
Max Arresting Distance of **24in.** & Average Arresting Force **900lbs.**

- Inspect webbing before each use
- Use in temperatures between 130°F & -40°F (54°C & -40°C)
- Do not repair unit
- Suitable for use with horizontal lifelines
- Structure must be capable of supporting 5,000lbs. (22kN)
- Store indoors
- Working Capacities: ANSI 130-310lbs, OSHA 130-420lbs.
- This unit must be anchored overhead, foot-level tie-off not permitted
- 2ft free fall limit


Materials:
3/16" Galvanized Steel Cable, Cable Sopper Handle, Steel Snap Hook, Swivel Trip and Carabiner Impact Resistant Polyurea, Hoisting Steel Hardware

Follow instructions for proper SRL attachment
 Do not use for fall arrest
 Do not use for rescue
 Do not use for rescue
 Do not use for rescue
 Do not use for rescue

MALTA DYNAMICS
800-494-1840 | MaltaDynamics.com
210 13th Street | Malta, OH 43758

Front

Back



C9001



WARNING:

Fully read and understand all manufacturer's instructions, which are provided and packaged with this equipment at time of shipment. **DO NOT ATTEMPT TO SELF SERVICE OR REPAIR THIS EQUIPMENT. DO NOT REMOVE THIS LABEL.** Use, maintain and inspect this equipment in accordance with manufacturer's instruction manual and labels included with this device at time of shipment.

Class A Max Arresting Distance: 24in. Average Arresting Force: 1350lbs	This SRL meets BOTH Classes simultaneously!	Class B Max Arresting Distance: 54in. Average Arresting Force: 1350lbs
--	---	--

Malta Dynamics Hybrid hog has
Max Arresting Distance of **24in.** & Average Arresting Force **900lbs.**

- Inspect webbing before each use
- Use in temperatures between 130°F & -40°F (54°C & -40°C)
- Do not repair unit
- Suitable for use with horizontal lifelines
- Structure must be capable of supporting 5,000lbs. (22kN)
- Store indoors
- Working Capacities: ANSI 130-310lbs, OSHA 130-420lbs.
- This unit must be anchored overhead, foot-level tie-off not permitted
- 2ft free fall limit

Materials:
3/16" Galvanized Steel Cable, Cable Sopper Handle, Steel Snap Hook, Swivel Trip and Carabiner Impact Resistant Polyurea, Hoisting Steel Hardware

Follow instructions for proper SRL attachment
 Do not use for fall arrest
 Do not use for rescue
 Do not use for rescue
 Do not use for rescue

MALTA DYNAMICS
800-494-1840 | MaltaDynamics.com
210 13th Street | Malta, OH 43758

C7002



WARNING:

Fully read and understand all manufacturer's instructions, which are provided and packaged with this equipment at time of shipment. **DO NOT ATTEMPT TO SELF SERVICE OR REPAIR THIS EQUIPMENT! DO NOT REMOVE THIS LABEL!** Use, maintain and inspect this equipment in accordance with manufacturer's instruction manual and labels included with this device at time of shipment.


OSHA COMPLIANT **ANSI COMPLIANT** **OSHA/ANSI Z359.14-2014**

MALTA DYNAMICS
800-494-1840 | MaltaDynamics.com
210 13th Street | Malta, OH 43758

HOG TRACKER
13.56 MHz Smart Tag. Scan tag for product updates & more!

Front

Back



C8000

PART# C8000

razorback
series

Heavy-Duty 20' Self-Retracting Lifeline
3/16" Galvanized Steel Cable with Swivel Top, Cable Stopper Handle, Swivel Snap Hook, and Carabiner

OSHA/ANSI 2359.14-2014
SRL Weight: 14.9 lbs.

Capacity: 1 person
ANSI Capacity Range: 130-310 lbs.
OSHA Maximum Capacity: 420 lbs.
Max Arresting Distance: 54 in.
Average Arresting Force: 900 lbs.


Materials: Aluminum Gravity Die Casting, Galvanized Steel Cable, Sanitoprene, Aluminum Alloy, High Strength Carbon Steel and Stainless Steel

MALTA DYNAMICS

Class B SRD

Front

Back



C8001

PART# C8001

razorback
series

Heavy-Duty 30' Self-Retracting Lifeline
3/16" Galvanized Steel Cable with Swivel Top, Cable Stopper Handle, Swivel Snap Hook, and Carabiner

OSHA/ANSI 2359.14-2014
SRL Weight: 15.52 lbs.

Capacity: 1 person
ANSI Capacity Range: 130-310 lbs.
OSHA Maximum Capacity: 420 lbs.
Max Arresting Distance: 54 in.
Average Arresting Force: 900 lbs.

Materials: Aluminum Gravity Die Casting, Galvanized Steel Cable, Sanitoprene, Aluminum Alloy, High Strength Carbon Steel and Stainless Steel

MALTA DYNAMICS

Class B SRD

WARNING:

Fully read and understand all manufacturer's instructions, which are provided and packaged with this equipment at time of shipment. **DO NOT ATTEMPT TO SELF SERVICE OR REPAIR THIS EQUIPMENT! DO NOT REMOVE THIS LABEL!** Use, maintain and inspect this equipment in accordance with manufacturer's instruction manual and labels included with this device at time of shipment.

SERIAL # _____
 BATCH # _____
 MFG. DATE _____

HOG TRACKER
13.56 MHz Smart Tap
Scan tag for product updates & more!

OSHA COMPLIANT 2359.14-2014
ANSI COMPLIANT Z359.14-2014
 OSHA/ANSI 2359.14-2014

MALTA DYNAMICS

800-494-1840
 210 13th Street | Malta, OH 43758
 MaltaDynamics.com

SINGLE & TWIN CONNECTIONS FOR C7102, C7103, C7104, C7201, C7202, & C7203

The sections that follow will deal specifically with the proper use and installation of the Pygmy Hog SRD model numbers C7102, C7103, C7104, C7201, C7202 and C7203 with C1004 Dual SRL Connector or the C1005 Dual SRL Connector.

About the Pygmy Hog SRD with C1004



Figure 1A: About the Pygmy Hog SRD

A	Integral Swivel Eye	D	Leg-End Connector
B	Unit Housing	E	Dual SRL Connector
C	Energy Absorber		



About the Pygmy Hog SRD with C1005




Figure 1B: About the Pygmy Hog SRD

A	Integral Swivel Eye	E	Triple-Lock Carabiner
B	Unit Housing	F	Alignment Clip
C	Energy Absorber	G	Triple-Lock Gate
D	Leg-End Connector		

Fall Clearance and Swing Falls

Figure 2: Fall Clearance and Swing Falls

Figure 2A:

Clearance required in feet (meters) between Working Level and Nearest Obstruction for User with Total Weight up to 310 lbs (140 kg). Do not tie off below the harness D-Ring.





Figure 2B:

Swing Falls



To determine the clearance required: Measure the distance from the user's harness dorsal connection to the anchorage for the Pygmy Hog SRL. Both horizontal and vertical distances are required. Use Figure 2A above to determine the required clearance between the working level and the nearest obstruction. The dotted lines in the figure represent 1 foot (0.3 m) increments from the user's harness dorsal connection to the anchorage. For example, 7 ft (2.1 m) of clearance is required when the Pygmy Hog unit is anchored 3 1/2 ft (1 m) above and 3 1/2 ft (1 m) to the side of the user's harness dorsal connection.

NOTE: The clearances provided above assume the fall occurs from the standing position. If the worker is kneeling or crouching an additional 3 ft (0.9 m) of clearance is needed.



Compatibility of Connectors

Connectors are considered to be compatible with connecting elements when they have been designed to work together in such a way that their sizes and shapes do not cause their gate mechanisms to inadvertently open regardless of how they become oriented. Contact Malta Dynamics if you have any questions about compatibility.

Connectors (hooks, carabiners, and D-rings) must be capable of supporting at least 5,000 lbs. (22.2 kN). Connectors must be compatible with the anchorage or other system components. Do not use equipment that is not compatible. Non-compatible connectors may unintentionally disengage. Connectors must be compatible in size, shape, and strength. Self-locking snap hooks and carabiners are required by ANSI Z359 and OSHA.

Installation & Use of the Self-Retracting Device

Use compatible connectors when connecting to the anchorage and ensure unintended disengagement cannot occur. Visually ensure all connectors close and lock securely.

The self-retracting device (SRD) is configurable into two orientation options, with the housing attached to the full body harness (FBH), or with the housing end attached to an approved anchorage. Inspect the SRD before each use in accordance with the procedures detailed in this manual. Before each use, ensure the SRD lifeline locks by slowly extracting a length of lifeline, then pull sharply on the lifeline. The SRD must lock and the lifeline must stop paying out.

Single Housing End Attached to the FBH

The SRD housing end is installed to the dorsal D-ring of an FBH and the leg end attached to a suitable anchorage.




Figure 3A: Pygmy Hog SRD Orientation and Acceptable Anchorage Range

6' & 11' Single-leg Attached to Dorsal D-ring

Shaded area indicates Range of Allowable Connection

To attach SRD on the Harness, Follow these steps:

1. Don the harness in accordance with the harness manufacturer's instructions.
2. Insert the nose end of an ANSI compatible double-locking carabiner through the SRD housing swivel eye.
3. Attach the carabiner to the dorsal D-ring of the FBH. Ensure the carabiner gate is fully closed and locked.
4. Connect the leg end connector to an approved, suitable anchor that meets work zone requirements.

The SRD will pay out and retract smoothly to maintain a taut line during normal movement. Work as directly under the anchor as possible.



Single Housing End Attached to the Anchorage

The housing end connector may be installed to a suitable anchorage.





Figure 3B: Pygmy Hog SRD Orientation and Acceptable Anchorage Range

6' & 11' Single-leg SRD Attached to Anchorage

Shaded area indicates Range of Allowable Connection

To attach the housing to an anchorage, follow these steps:

1. Don the harness in accordance with the harness manufacturer's instructions.
2. Insert the nose end of an ANSI compatible double-locking carabiner through the SRD housing swivel eye.
3. Attach the carabiner to the anchor point. Visually ensure the carabiner is fully closed and locked.
4. Connect the leg end connector to the dorsal D-ring of the FBH. Visually ensure the connector is fully closed and locked.

The SRD will pay out and retract smoothly to maintain a taut line during normal movement. Work as directly under the anchor as possible. If necessary, the leg end connector may be attached to a lower level anchorage, up to 5' below the user's harness D-ring. Be aware that a lower anchorage increases the risk of injury due to swing fall. Additional fall clearance is required.

DO NOT attach the SRD leg end to the FBH with a rebar hook or any large-throat snap hook or large carabiner. A side load could cause an unintentional disengagement. Use small snap hooks only.

DO NOT attach the housing to the FBH with a rebar hook or any large-throat snap hook or large carabiner. A side load could cause unintentional disengagement.

Twin-leg SRDs

Twin-leg SRD housing ends are attached to the straps of a properly adjusted and fitted FBH with a specially-configured triple-locking twin-SRD carabiner. Connect the leg ends to anchorages within the correct orientation range. Refer to Figure 3C.




Figure 3C: Pygmy Hog SRD Orientation and Acceptable Anchorage Range

6' & 11' Twin-leg SRD Attached to Full Body Harness

Shaded area indicates Range of Allowable Connection

DO NOT attempt to install the twin SRDs specially configured carabiner to an anchorage.

CAUTION: Do **NOT** connect the leg ends of twin SRDs to two anchorages at the same time, except for the brief time when transitioning from one anchorage to another.




Installing the C1004

To install the SRD housings onto the FBH, follow the procedure detailed in Figure 5A:


1. Prepare Dual Connector for Attachment
2. Prepare FBH and Preliminary Attachment

Figure 5A: Attaching Twin-leg SRD to FBH with C1004

Understanding C1004 Parts



1. Prepare Dual Connector for Attachment




1. Prepare Dual Connector for attachment:
(A) Push and hold both Release Buttons while simultaneously pulling out the Gate/Lock Bar. **(B)** Take note of the red Locking Indicator which should no longer be visible once installation is complete. **(C)** Attach SRLs to Dual Connector.

2. Prepare FBH and Preliminary Attachment




2. Prepare FBH and Preliminary Attachment:
(D) Lift the *Dorsal D-ring* to the up-pointing position. Then loosen the intersection of the two web straps that pass through the D-ring slot to create *slacked loops* of about 2" or 3". **(E)** Insert the Gate/Locking Bar of the Carabiner into the two intersecting slacked loops. **(F)** Slide the Gate/Lock Bar back to the fully closed position. Ensure that the red Locking Indicator is not visible. **(G)** Remove the slacked loops from the intersecting web straps by pulling up through the D-ring slot and the D-ring holder.



WARNING

Ensure the carabiner is correctly installed on the FBH as shown in Figure 5A. Incorrect installation may result in serious injury or death.

Figure 5B shows common INCORRECT connections.



A - DO NOT Attach directly to the Dorsal D-ring

B - DO NOT Attach to only one of the intersecting web straps

C - DO NOT Attach to intersecting web straps over/above the Dorsal D-ring

D - DO NOT Attach anywhere outside the intersecting web straps

E - CORRECT attachment to both intersecting web straps with Dorsal D-ring in the up position



Installing the C1005

To install the SRD housings onto the FBH, follow the procedure detailed in Figure 6A:

1. Prepare Twin-leg SRD for Attachment
2. Prepare FBH and Preliminary Attachment
3. Reinstating 2nd SRD Unit
4. Closing and Securing

Figure 6A: Attaching Twin-leg SRD to FBH

1. Prepare Twin-leg SRD for Attachment



1. Prepare Single-leg for attachment:
(A) Open the Alignment Clip from the reverse side by pushing on the *top ears* to release and (B) allow clip to rotate downward; next, (C) rotate to one side one SRD unit and the clip then open open the triple-lock gate on the Carabiner and remove the other SRD unit. Allow gate to close.

2. Prepare FBH and Preliminary Attachment



2. Prepare FBH and Preliminary Attachment:
(D) Lift the *Dorsal D-ring* to the up-pointing position. Then loosen the intersection of the two web straps that pass through the D-ring slot to create *slacked loops* of about 2" or 3". (E) With only one SRD unit still connected to the Carabiner, reopen the gate and insert the *nose* of the Carabiner into the two intersecting slacked loops; (F) allow the gate to close while the Alignment Clip remains positioned on the gate only.

3. Reinstating the 2nd SRD Unit



3. Reinstating the 2nd SRD Unit:
(G) Now rotate the Carabiner and Alignment Clip 1/4 turn to the horizontal position; while keeping slack in the web loops, the gate and clip will end up positioned below the loops. (H) Keeping the Carabiner Horizontal, rotate the SRD unit away from the gate and slide the Alignment Clip off and away from the gate as well. (I) Open the Carabiner gate and insert the nose through the swivel eye of the second SRD unit. Then allow the gate to close to capture the second SRD. (J) Next, reposition the Alignment Clip back onto the gate.

4. Closing and Securing




4. Closing and Securing:
(K) With the Alignment Clip on the gate, rotate the clip upward. Then tightly pinch the two web straps together and insert between the ears of the clip and snap the ears to the body of the Carabiner. (L) Lastly, remove the slacked loops from the intersecting web straps by pulling up through the D-ring slot and the D-ring holder. Check the gate for full closure and the Alignment Clip to be securely snapped to the Carabiner body. Don your FBH and adjust as needed for proper fit.

WARNING

Ensure the carabiner is correctly installed on the FBH as shown in Figure 6A. Incorrect installation may result in serious injury or death.

Figure 6B shows common INCORRECT connections.



A - DO NOT Attach directly to the Dorsal D-ring

B - DO NOT Attach to only one of the intersecting web straps

C - DO NOT Attach to intersecting web straps over/above the Dorsal D-ring

D - DO NOT Attach anywhere outside the intersecting web straps

E - CORRECT attachment to both intersecting web straps with Dorsal D-ring in the up position



Twin-leg SRD Work Zone Transition

This SRD is designed for attachment of one leg end at a time during work performance. Dual connection is for transitioning from one work zone to another only, as shown in Figure 7.

Attach one leg end connector to a suitable anchor. The user may then move to another work location and attach the unused leg to another suitable anchorage. Detach the original attached leg. Repeat the procedure, until the desired work location is reached.

DO NOT allow the lifelines to become tangled or twisted together as this may prevent them from retracting.

DO NOT allow any lifeline to pass under arms or between legs during use.

DO NOT clamp, knot, or prevent the lifeline from retracting or being taut.

DO NOT lengthen the SRD by connecting a lifeline or similar component.

DO NOT allow the lifeline to freewheel back into the housing.




Figure 7: Use of Twin-leg SRDs for Lateral Movement

A	Original Work Location before lateral movement
B	Starting lateral movement; one leg connected to Anchor
C	During lateral move; both legs connected in momentary transition between Anchors
D	Ending lateral movement; one leg connected to Anchor
E	New Work Location after lateral movement

Pygmy Hog SRLs MUST NEVER be used in Leading Edge (LE) applications.

No free fall is allowed.

ALWAYS avoid lifeline contact with sharp or abrasive edges and surfaces.

SRL must always be positioned at or above harness dorsal d-ring AND at or below anchor point.

WARRANTY

THE FOLLOWING IS MADE IN LIEU OF ALL WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Equipment offered by Malta Dynamics is warranted against factory defects in workmanship and materials for a period of one year from date of installation or first use by the original owner. LIMITED REMEDY: Upon notice in writing, Malta Dynamics will repair or replace all defective items at Malta Dynamics's sole discretion. Malta Dynamics reserves the right to require that the defective item be returned to its plant for inspection before determining the appropriate course of action. Warranty does not cover equipment damage resulting from wear, abuse, damage in transit, failure to maintain the product or other damage beyond the control of Malta Dynamics. Malta Dynamics shall be the sole judge of product condition and warranty options. This warranty applies only to original purchaser and is the only warranty applicable to this product. Please contact Malta Dynamics customer service department at 800-494-1840 for assistance. LIMITATION OF LIABILITY: IN NO EVENT WILL MALTA DYNAMICS BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES INCLUDING, BUT NOT LIMITED TO LOSS OF PROFITS, IN ANY WAY RELATED TO THE PRODUCTS REGARDLESS OF THE LEGAL THEORY ASSERTED.



MALTA DYNAMICS

800-494-1840
MaltaDynamics.com
210 13th Street
Malta, OH 43758 USA







MALTA DYNAMICS

800-494-1840
MaltaDynamics.com
210 13th Street
Malta, OH 43758 USA