

# SIEMENS

## SINAMICS

### V60

## Controlled Power Module (CPM60.1)

### Getting Started

#### Legal information

#### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

<b>⚠ DANGER</b>
indicates that death or severe personal injury <b>will</b> result if proper precautions are not taken.
<b>⚠ WARNING</b>
indicates that death or severe personal injury <b>may</b> result if proper precautions are not taken.
<b>⚠ CAUTION</b>
indicates that minor personal injury can result if proper precautions are not taken.
<b>NOTICE</b>
indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

#### Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

#### Proper use of Siemens products

Note the following:

<b>⚠ WARNING</b>
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

## Preface

This Getting Started is an English-Chinese bilingual version. Since V01.07, the performance of the drive in the default status has become more dynamic than that of the earlier version. If you want to work in the earlier status, you can change the current default value to the second default value (see Section 3.1.2).

# Table of contents

	<b>Preface</b> .....	<b>2</b>
<b>1</b>	<b>General information</b> .....	<b>4</b>
	1.1 System overview .....	4
	1.2 Safety notes .....	5
	1.3 Identification.....	7
	1.4 Technical data.....	10
<b>2</b>	<b>Installation</b> .....	<b>12</b>
	2.1 Mechanical installation .....	12
	2.1.1 Mounting the drive.....	12
	2.1.2 Mounting the motor .....	14
	2.2 Electrical installation.....	15
	2.3 Interface definition.....	18
	2.4 Signal sequence example .....	21
<b>3</b>	<b>Commissioning</b> .....	<b>22</b>
	3.1 Commissioning .....	22
	3.1.1 Main menu .....	22
	3.1.2 Function menu .....	24
	3.1.3 Setpoints from NC.....	26
	3.1.4 First commissioning .....	27
	3.1.5 System commissioning .....	28
	3.2 Parameter list.....	29
	3.3 Display data list.....	31
<b>4</b>	<b>Troubleshooting</b> .....	<b>32</b>
	4.1 LED status indicators .....	32
	4.2 Alarms.....	33
	4.3 Errors during drive self-test .....	37
	4.4 Other faults .....	38
<b>A</b>	<b>Appendix</b> .....	<b>38</b>
	A.1 Order numbers.....	38
	A.2 Technical support.....	39


# 1 General information

## 1.1 System overview

### System overview

The SINAMICS V60 servo drive system is a new drive system developed by Siemens. It's designed for use with a Siemens SINUMERIK 808D numerical controller to control the operation of a CNC turning or milling machine, and it can also be connected with a Siemens SIMATIC PLC.

The following picture illustrates possible system configuration (taking the SINUMERIK 808D turning variant as an example).



## 1.2 Safety notes

### General

 <b>WARNING</b>
<b>Operation conditions</b> Only qualified personnel should be allowed to work on this drive system, and only after becoming acquainted with all the safety notices regarding installing, connecting, commissioning, operation and maintenance as set out in this manual. Failure to observe these notices contained in this manual can result in death, severe personal injury or considerable damage to property. Without prior authorization, you are not allowed to perform any modification on the drive.

### Identification

 <b>WARNING</b>
<b>Deliverables received must be complete and intact.</b> Exercise caution to ensure that you do not put a damaged device into service. Make sure that the drive, the motor and the cables received correspond with the specific drive package you ordered from Siemens.

### Transport & Storage

 <b>CAUTION</b>
<b>Drive transport and storage</b> Transport and storage must meet specified environmental conditions. Do not handle the motor by gripping the connecting cable (power cable, brake cable or encoder cable) or the motor shaft.

### Mechanical installation

 <b>WARNING</b>
<b>Installation environment</b> Use caution to ensure that you do not install the drive and the motor in an area which is subject to inflammables or combustibles, water or corrosion hazards. Failure to observe may result in fire or electric shock. Do install the drive in a distribution cabinet with an adequate protection level.

 <b>CAUTION</b>
<b>Mounting locations and clearance</b> Do not install the drive and the motor in a location where it is likely to be exposed to constant vibrations or physical shocks. Risk of fire. Make sure that no any foreign body (such as chips of wood or metal, dust, paper scraps, etc.) falls into the drive or lies on its heatsink. Keep sufficient clearance between drives, one drive and another device/inner wall of the cabinet.

<b>NOTICE</b>
<b>Tightening the screw on the terminal door</b> Siemens recommends that you tighten the screw on the terminal door of the drive, after you have completed the installation work.

## Electrical installation

### WARNING

#### Connection requirements

The drive must have been disconnected from the power supply for at least five minutes before you perform any wiring to it. Make sure that all connections are correct and reliable, and the drive and motor are always properly grounded.

Do suppress radio interference according to EN61800, category C3 (for industrial environment only).

SINAMICS V60 is an open-loop drive system, so it has no protection against wire breaks.

### CAUTION

#### Connection requirements

The drive must connect to the motor directly with no capacitor, inductor or filter, etc. installed between them.

The mains supply voltage must fall in the range of voltage limits.

It is strictly prohibited to wire the mains input cable to motor terminals U, V, W or to wire a power cable to the line input terminals L1, L2, L3.

It is strictly prohibited to wire motor terminals U, V,W on the drive in an incorrect phase sequence.

If the whole system has to be qualified with CE mark, please use shielded cables for power cable, mains input cable and brake cable.

Always install a 380 V three-phase AC isolating transformer at a mains supply network for protective separation.

Route signal cables separately from power cables and lay them in different cable conduits.

Keep the signal cables a minimum of 10 cm away from the power cables.

Keep cables already connected away from rotating mechanical parts.

## Commissioning/Operation

### WARNING

#### Commissioning/operation requirements

Before switching the power on, make sure that the drive system has been reliably installed and connected, and the mains voltage falls in the permitted voltage limits.

Do not touch the motor shaft when the motor is running. Failure to comply may cause personal injury.

Ensure that all connections to the SINAMICS V60 drive module have been disconnected before you perform any voltage test (according to EN60201-1 (VDE0112-1), Article 20.4) for an electrical device on the machine tool. The drive had passed the insulation test before its delivery to the customer and doesn't require a second test (for avoiding additional voltage stress).

The motor brake is only used for brake control over motor start/stop. Unless absolutely necessary, do not apply it as an emergency stop mechanism.

### CAUTION

#### Commissioning/operation requirements

Only after you have successfully carried out commissioning of the drive system while the motor operates under dry-run conditions, can you perform commissioning of the drive system while the motor operates under loaded conditions.

Do not touch the heatsink of the drive, the motor or other high-temperature parts during equipment running or within a certain period since power disconnection. Failure to comply may cause personal injury.

Ensure that you do not switch on/off the power frequently. This may cause damage to the drive system.



The motor rotation direction is determined according to your view from the motor shaft end. Viewing from the motor shaft end, counterclockwise (CCW) rotation is defined as forward rotation while clockwise (CW) rotation is defined as reverse rotation.

# 1.3 Identification


## Scope of delivery

Siemens provides customers with the following components.


Component	Illustration	Remark
<b>Components included in the drive unit package</b>		
Controlled Power Module CPM60.1	4 A 6 A 7 A 	Dimension (W × H × D; in mm): 106 × 226 × 200
	10 A 	Dimension (W × H × D; in mm): 123 × 226 × 200
Getting Started		--
Cable clamps (2 pieces)		Applicable to both shielded and non-shielded cables
<b>Components included in the motor unit package</b>		
1FL5 motor	 With the brake 4 Nm 6 Nm 7.7 Nm 10 Nm	Refer to the rating plate on the motor housing for motor-specific electrical data. 1FL5 motors have two main types - with key and without key. Each type involves motors with brakes and without brakes.
	 Without the brake 4 Nm 6 Nm 7.7 Nm 10 Nm	
Datasheet for 1FL5 motor		--

Component	Illustration	Remark
<b>Cables individually packaged</b>		
Power cable (unshielded)	<p data-bbox="451 271 703 322">Drive side (to motor interface U,V,W)</p>  <p data-bbox="703 488 874 539">Motor side (to motor socket)</p>	<p data-bbox="986 264 1433 322">For each cable, four lengths are available for your selection:</p> <ul data-bbox="986 331 1082 465" style="list-style-type: none"> <li>• 3 m</li> <li>• 5 m</li> <li>• 7 m</li> <li>• 10 m</li> </ul>
Brake cable (unshielded)	<p data-bbox="451 586 727 638">Drive side (to motor brake interface X3)</p>  <p data-bbox="592 696 818 748">Motor side (to motor brake socket)</p>	
Encoder cable (shielded)	<p data-bbox="483 797 727 848">Drive side (to encoder interface X7)</p>  <p data-bbox="687 996 874 1048">Motor side (to encoder socket)</p>	

Drive rating plate (example)




Drive rating plate



Drive variant/rated output current	Order number
4A	6SL3210-5CC14-0UA0
6A	6SL3210-5CC16-0UA0
7A	6SL3210-5CC17-0UA0
10A	6SL3210-5CC21-0UA0

Motor rating plate (example)



# 1.4 Technical data

## Technical data for CPM60.1 Drive Modules

Order No. : 6SL3210-	5CC14-0UA0	5CC16-0UA0	5CC17-0UA0	5CC21-0UA0
<b>General performance</b>				
Rated output current	4 A	6 A	7 A	10 A
Max. output current	8 A	12 A	14 A	20 A
Rated output power	0.8 kW	1.2 kW	1.6 kW	2.0 kW
Rated input power	0.9 kW	1.4 kW	1.9 kW	2.3 kW
Rated motor torque	4 Nm	6 Nm	7.7 Nm	10 Nm
Application field	Turning machines, milling machines, engraving, packaging, printing etc.			
Configurable controller	SINUMERIK 808D, SIMATIC S7-200 and SIMATIC S7-1200			
Axis	Single-axis drive			
Display	6-digit, 7-segment LED display, two LED status indicators			
Keys on panel	4 tact switch keys			
Setpoint interface	Pulse interface			
Overload capability				
Applicable load inertia	≤ 5 times of motor inertia			
<b>Control performance</b>				
Control mode	1. Position control (Input mode: pulse + direction signals) 2. JOG mode			
Input pulse frequency	≤ 333 kHz			
Drive input	1. Servo enable 2. Alarm cancel			
Drive output	1. Brake output 2. Servo alarm 3. Servo ready 4. Zero mark			
Protection functions	Overcurrent, overvoltage, undervoltage, overload, IGBT overtemperature, overspeed, encoder abnormal protections, I <sup>2</sup> t detection			
Encoder	TTL encoder 2500p/r with U, V, W rotor position signal; one zero mark			
Mains supply voltage	Rated voltage: 3 AC 220 V to 240 V Tolerance: - 15 % ~ + 10 % 50/60 Hz, unregulated DC-Link			
<b>Environmental conditions</b>				
Ambient temperature	Operation	0 to 45 °C: without power derating (100% load); 45 to 55 °C: with power derating (by 0% at 45 °C up to 30% at 55 °C).		


Order No. : 6SL3210-

5CC14-0UA0

5CC16-0UA0

5CC17-0UA0

5CC21-0UA0



Transportation -40 °C to 70 °C

Storage -25 °C to 55 °C

Relative humidity &lt; 95 %

Vibration resistance Operation ≤ 1 G (0.075 mm)

Transport &amp; storage ≤ 2 G (7.5 mm)

Installation altitude < 1,000 m above sea level: without power derating;  
1,000 to 2,000 m: with power derating (derated to 80%)

Protection class IP20

**Mechanical design**

Outline dimensions (W x H x D)	106 x 226 x 200 mm	106 x 226 x 200 mm	106 x 226 x 200 mm	123 x 226 x 200 mm

**NOTICE****Motor specifications**

For technical data of the motor, please refer to the Motor Specification delivered with the motor.

**Technical data for transformer****Recommended transformer type** 380 V/220 V SG series 3AC isolating transformerSupply voltage 3 AC 380 V/220 V  
50/60 Hz

Connection group Y/Y-12

Impedance voltage (U<sub>k</sub>%) 4No-load current (%) For a transformer ≤ 1.0 kVA, the no-load current < 18%  
For a transformer > 1.0 kVA, the no-load current < 14%

Power selection (for standard turning/milling machines)	Possible motor combination	Transformer power (apparent power)
	4 Nm	1.0 kVA
6 Nm	1.5 kVA	
7.7 Nm	2.0 kVA	
10 Nm	2.5 kVA	
4 Nm + 4 Nm	1.5 kVA	
4 Nm + 6 Nm	1.5 kVA	
4 Nm + 7.7 Nm	1.5 kVA	
4 Nm + 10 Nm	2.0 kVA	
6 Nm + 6 Nm	2.0 kVA	
6 Nm + 7.7 Nm	2.0 kVA	
6 Nm + 10 Nm	2.5 kVA	
7.7 Nm + 7.7 Nm	2.0 kVA	

Recommended transformer type	380 V/220 V SG series 3AC isolating transformer	
	7.7 Nm + 10 Nm	2.5 kVA
	10 Nm + 10 Nm	3.0 kVA
	4 Nm + 4 Nm + 4 Nm	1.5 kVA
	4 Nm + 4 Nm + 6 Nm	1.5 kVA
	4 Nm + 4 Nm + 7.7 Nm	2.1 kVA
	4 Nm + 4 Nm + 10 Nm	2.0 kVA
	4 Nm + 6 Nm + 6 Nm	2.0 kVA
	4 Nm + 6 Nm + 7.7 Nm	2.0 kVA
	4 Nm + 6 Nm + 10 Nm	2.5 kVA
	4 Nm + 7.7 Nm + 7.7 Nm	2.5 kVA
	4 Nm + 7.7 Nm + 10 Nm	2.5 kVA
	4 Nm + 10 Nm + 10 Nm	3.0 kVA
	6 Nm + 6 Nm + 6 Nm	2.0 kVA
	6 Nm + 6 Nm + 7.7 Nm	2.0 kVA
	6 Nm + 6 Nm + 10 Nm	2.5 kVA
	6 Nm + 7.7 Nm + 7.7 Nm	2.5 kVA
	6 Nm + 7.7 Nm + 10 Nm	2.5 kVA
	6 Nm + 10 Nm + 10 Nm	3.0 kVA
	7.7 Nm + 7.7 Nm + 7.7 Nm	2.5 kVA
	7.7 Nm + 7.7 Nm + 10 Nm	3.0 kVA
	7.7 Nm + 10 Nm + 10 Nm	3.0 kVA
	10 Nm + 10 Nm + 10 Nm	3.5 kVA

### CAUTION

#### Use of an appropriate isolating transformer

To reduce the risk of electric shock, interference from power supply and electromagnetic field, an isolating transformer is necessary for the 3AC 380V mains system.


The customer may select the right transformer with reference to the table above (Determine the right transformer power based on desired motor combinations)


## 2 Installation

### 2.1 Mechanical installation

#### 2.1.1 Mounting the drive

Drill pattern and outline dimensions






### Mounting method

You mount the drive with four M5 screws to the inner wall of the cabinet. Note that the drive must be mounted vertically to the cabinet wall, with the ventilation openings of the drive pointing upwards. The screw tightening torque of the drive must be no more than 2.0 Nm.

### Minimum mounting clearance

To ensure sufficient heat dissipation, please observe the requirements for minimum clearance between drives, one drive and another device/inner wall of the cabinet, as illustrated in the picture below:



### The use of supplied cable clamps

If the CE marking requirements for cables are mandatory, the mains input cable and the power cable used must all be shielded type of cables. In that case, you can use the cable clamps as a ground connection between the cable shielding layer and a common ground point.

Clamps can also be helpful in better fixing cables (the unshielded power cable and the mains input cable) in place.

The illustration below shows you how to use the clamps to fix both cables and to make a shielding connection with the cable.



**Note**

For motors with keys, the flat key size is as shown in the above figure.

For the key way size, refer to the national standard GB/T 1095-2003

For the flat key size, refer to the national standard GB/T 1096-2003 (key C 8X7X40)


**Mounting orientation and ingress protection requirements**

You can mount a motor vertically or horizontally. Make sure that no fluid (water, oil, etc.) can penetrate into the motor while installation or motor operation. Keep the cable outlet pointing downwards if a motor is mounted horizontally, in order to protect the motor from ingress of oil or water.


## 2.2 Electrical installation

### Connecting the drive with the SINUMERIK 808D CNC Controller

For a turning variant, the SINUMERIK 808D is designed to control three axes, including two feed axes (connected with the SINAMICS V60) and one spindle. For a milling variant, the SINUMERIK 808D is designed to control four axes, including three feed axes (connected with the SINAMICS V60) and one spindle. The connection diagram below takes interface X51 (axis X) for example to show you a system connection between the SINAMICS V60 and the SINUMERIK 808D.



## Connecting the drive with the SIMATIC PLC





### Note



When using the drive together with the SIMATIC PLC, you are recommended to use a standard 24 V DC power supply for the SIMATIC PLC and use a Siemens cable (6ES7298-2DS23-0XA0) to connect the two ones.

- If the SIMATIC PLC is an S7-200 controller, see the following wiring diagrams:

#### •For PNP types (example)



#### •For NPN types (example)



---

**Note**

As 65 signal from SINAMICS V60 drive is recommended for emergency stop, it is not used in SIMATIC PLC/SINAMICS V60 signal cable.


For a SIMATIC PLC (S7-200 series), signal PULS can only be connected to output terminal Q0.0 or Q0.1, and terminal Q0.2 or Q0.3 is used for direction output.

For PNP and NPN types, connectors on X5 are differently arranged. So, be sure to connect to X5 correctly according to the actual situation.

Based on contact colors, connect the contacts on the PLC (left) and those on the V60 (right) respectively, as shown on page EN-13. The contact colors on the PLC, however, do not match those on the V60.

---

- If the SIMATIC PLC is an S7-1200 controller, see the following wiring diagram (example):



---

**Note**

As 65 signal from SINAMICS V60 drive is recommended for emergency stop, it is not used in SIMATIC PLC/SINAMICS V60 signal cable.

For a SIMATIC PLC (S7-1200 series), signal PULS can only be connected to output terminal Q0.0 or Q0.2, and terminal Q0.1 or Q0.3 is used for direction output.

---

**External 24 V DC Power Supply**

The CPM60.1 drive unit should be connected to an external 24 V DC power supply (rated input current 2 A), which enables the drive to normally work under the voltage range of 24 V (-15% to +20%). Since the excellent quality of a DC power supply is critical to the stable operation of a drive system, Siemens recommends you to select a Siemens DC 24 V stabilized power supply (order number: 6EP1333-3BA00). If there is no Siemens DC 24 V power supply available, you can use a non-Siemens high-quality power supply instead.

**Filter**

A line filter (rated current 16 A, protection level IP20) is required so that the system can pass the CE certification (radiated emission test or conducted emission test). The filter recommended by SIEMENS has an order number of 6SN1111-0AA01-1BA1.

**Circuit breaker**


You can install a mains linear breaker (rated current: 15 A for 7 A or 10 A version of the drive and 10 A for 4 A or 6 A version of the drive; rated voltage: 250 V AC) to protect the system.

**SIMATIC PLC/SINAMICS V60 signal cable**



It is recommended to use SIEMENS-designed SIMATIC PLC/SINAMICS V60 signal cable (length: 3 m) to connect SIMATIC PLC and SINAMICS V60. This signal cable can be ordered with MLFB of 6ES7298-2DS23-0XA0.

## 2.3 Interface definition



### Line supply connection L1, L2, L3

Interface	Signal name	Description
	L1	Line phase L1
	L2	Line phase L2
	L3	Line phase L3
	Maximum conductor cross-section: 2.5 mm <sup>2</sup>	


### Motor output connection U, V, W

Interface	Signal name	Description	Schematic connection diagram
	U	Motor phase U	<p>Drive side (Terminal strip)      Motor side (Socket connector)</p> <p>Yellow-Green</p> 
	V	Motor phase V	
	W	Motor phase W	
	Maximum conductor cross-section: 2.5 mm <sup>2</sup>		



### Motor brake connection X3

Interface	Signal name	Description	Schematic connection diagram
	B+	+ 24 V, motor brake voltage positive	<p>Drive side (Terminal strip)      Motor side (Socket connector)</p> 
	B-	0 V, motor brake voltage negative	
	Maximum conductor cross-section: 1.5 mm <sup>2</sup>		




### DC 24 V power supply connection X4

Interface	Signal name	Description	Remark
	24 V	DC 24 V	Voltage 24 V DC (20.4 - 28.8 V) Current consumption: <ul style="list-style-type: none"> <li>• Max. 0.8 A without brake power supply</li> <li>• Max. 1.4 A with brake power supply</li> </ul>
	0 V	0 V	
	PE	Protective earth	--
	Maximum conductor cross-section: 1.5 mm <sup>2</sup>		

### Setpoint interface X5

Interface	Pin	Signal name	Description	I/O type	Remark
 <p>5V differential signal</p> <p>Too high input voltage may cause a damage to the device.</p>	1	+PULS	Pulse input setpoint +	I	<p>It is recommended that the differential drive mode is used here so that the pulse data can be transmitted correctly.</p> 
	2	-PULS	Pulse input setpoint -	I	
	3	+DIR	Direction of motor setpoint +	I	
	4	-DIR	Direction of motor setpoint -	I	
	5	+ENA	Pulse enable +	I	
	6	-ENA	Pulse enable -	I	
<p>Max. conductor cross section: 0.5 mm<sup>2</sup></p> <p>If the drive is connected with a SIMATIC PLC, please make sure that the time delay between PULS and DIR signals should be more than 16 µs.</p> <p>Please ensure that all the terminals of interface X5 should be firmly wired, otherwise, it is forbidden to start the machine.</p>					

### Digital I/O interface X6

Interface	Pin	Signal name	Description	I/O type	Remark
	1	65	Servo enable	I	+24 V = drive enable 0 V = drive disable
	2	RST	Alarm cancel	I	+24 V = high active <sup>1)</sup>
	3	M24	Servo enable and alarm cancel reference ground, 0 V	I	
	4	ALM1	Alarm relay contact 1 terminal	-	 <p>ALM1</p> <p>ALM2</p> <p>Internal relay terminals Relay picks up in case of an alarm. NC can receive this alarm from drive.</p>
	5	ALM2	Alarm relay contact 2 terminal	-	
	6	RDY1	Servo ready contact 1 terminal	-	 <p>RDY1</p> <p>RDY2</p> <p>Internal relay terminals Relay picks up when drive is ready for operation</p>
	7	RDY2	Servo ready contact 2 terminal	-	
	8	+24 V	Zero mark power supply	I	
	9	Z-M	Zero mark output	O	Pulse width: 2~3 ms H = + 24 V, L = 0 V
	10	M24	Zero mark reference ground 0 V	I	
<p>Maximum conductor cross section: 1.5 mm<sup>2</sup></p>					


<sup>1)</sup> To cancel an active alarm, apply a high level (+24 V) at this terminal.

### Encoder interface X7


Interface	Pin	Signal name	Description																																																																				
	24	A+	TTL encoder A phase signal																																																																				
	12	A-																																																																					
	23	B+	TTL encoder B phase signal																																																																				
	11	B-																																																																					
	22	Z+	TTL encoder Z phase signal																																																																				
	10	Z-																																																																					
	21	U+	TTL encoder U phase signal																																																																				
	9	U-																																																																					
	20	V+	TTL encoder V phase signal																																																																				
	8	V-																																																																					
	19	W+	TTL encoder W phase signal																																																																				
	7	W-																																																																					
	13	NC	Not connected (reserved)																																																																				
	25	NC																																																																					
	5/6/17/18	EP5	Encoder power supply +5 V																																																																				
	1/2/3/4	EM	Encoder power supply GND																																																																				
	<table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;">           Drive side (25-pin socket connector X7)         </td> <td style="width: 10%; text-align: center; vertical-align: middle;"> </td> <td style="width: 40%; vertical-align: top;">           Motor side (15-pin socket connector)         </td> </tr> <tr> <td style="vertical-align: top;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>A+</td><td>24</td></tr> <tr><td>A-</td><td>12</td></tr> <tr><td>B+</td><td>23</td></tr> <tr><td>B-</td><td>11</td></tr> <tr><td>Z+</td><td>22</td></tr> <tr><td>Z-</td><td>10</td></tr> <tr><td>U+</td><td>21</td></tr> <tr><td>U-</td><td>9</td></tr> <tr><td>V+</td><td>20</td></tr> <tr><td>V-</td><td>8</td></tr> <tr><td>W+</td><td>19</td></tr> <tr><td>W-</td><td>7</td></tr> <tr><td>EP5</td><td>5/6/17/18</td></tr> <tr><td>EM</td><td>1/2/3/4</td></tr> <tr><td>N.C.</td><td>13</td></tr> <tr><td>N.C.</td><td>25</td></tr> </table> </td> <td></td> <td style="vertical-align: top;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>4</td><td>A+</td></tr> <tr><td>7</td><td>A-</td></tr> <tr><td>5</td><td>B+</td></tr> <tr><td>8</td><td>B-</td></tr> <tr><td>6</td><td>Z+</td></tr> <tr><td>9</td><td>Z-</td></tr> <tr><td>10</td><td>U+</td></tr> <tr><td>13</td><td>U-</td></tr> <tr><td>11</td><td>V+</td></tr> <tr><td>14</td><td>V-</td></tr> <tr><td>12</td><td>W+</td></tr> <tr><td>15</td><td>W-</td></tr> <tr><td>2</td><td>EP5</td></tr> <tr><td>3</td><td>EM</td></tr> <tr><td>1</td><td>PE</td></tr> </table> </td> </tr> </table>				Drive side (25-pin socket connector X7)		Motor side (15-pin socket connector)	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>A+</td><td>24</td></tr> <tr><td>A-</td><td>12</td></tr> <tr><td>B+</td><td>23</td></tr> <tr><td>B-</td><td>11</td></tr> <tr><td>Z+</td><td>22</td></tr> <tr><td>Z-</td><td>10</td></tr> <tr><td>U+</td><td>21</td></tr> <tr><td>U-</td><td>9</td></tr> <tr><td>V+</td><td>20</td></tr> <tr><td>V-</td><td>8</td></tr> <tr><td>W+</td><td>19</td></tr> <tr><td>W-</td><td>7</td></tr> <tr><td>EP5</td><td>5/6/17/18</td></tr> <tr><td>EM</td><td>1/2/3/4</td></tr> <tr><td>N.C.</td><td>13</td></tr> <tr><td>N.C.</td><td>25</td></tr> </table>	A+	24	A-	12	B+	23	B-	11	Z+	22	Z-	10	U+	21	U-	9	V+	20	V-	8	W+	19	W-	7	EP5	5/6/17/18	EM	1/2/3/4	N.C.	13	N.C.	25		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>4</td><td>A+</td></tr> <tr><td>7</td><td>A-</td></tr> <tr><td>5</td><td>B+</td></tr> <tr><td>8</td><td>B-</td></tr> <tr><td>6</td><td>Z+</td></tr> <tr><td>9</td><td>Z-</td></tr> <tr><td>10</td><td>U+</td></tr> <tr><td>13</td><td>U-</td></tr> <tr><td>11</td><td>V+</td></tr> <tr><td>14</td><td>V-</td></tr> <tr><td>12</td><td>W+</td></tr> <tr><td>15</td><td>W-</td></tr> <tr><td>2</td><td>EP5</td></tr> <tr><td>3</td><td>EM</td></tr> <tr><td>1</td><td>PE</td></tr> </table>	4	A+	7	A-	5	B+	8	B-	6	Z+	9	Z-	10	U+	13	U-	11	V+	14	V-	12	W+	15	W-	2	EP5	3	EM	1
Drive side (25-pin socket connector X7)		Motor side (15-pin socket connector)																																																																					
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>A+</td><td>24</td></tr> <tr><td>A-</td><td>12</td></tr> <tr><td>B+</td><td>23</td></tr> <tr><td>B-</td><td>11</td></tr> <tr><td>Z+</td><td>22</td></tr> <tr><td>Z-</td><td>10</td></tr> <tr><td>U+</td><td>21</td></tr> <tr><td>U-</td><td>9</td></tr> <tr><td>V+</td><td>20</td></tr> <tr><td>V-</td><td>8</td></tr> <tr><td>W+</td><td>19</td></tr> <tr><td>W-</td><td>7</td></tr> <tr><td>EP5</td><td>5/6/17/18</td></tr> <tr><td>EM</td><td>1/2/3/4</td></tr> <tr><td>N.C.</td><td>13</td></tr> <tr><td>N.C.</td><td>25</td></tr> </table>	A+	24	A-	12	B+	23	B-	11	Z+	22	Z-	10	U+	21	U-	9	V+	20	V-	8	W+	19	W-	7	EP5	5/6/17/18	EM	1/2/3/4	N.C.	13	N.C.	25		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>4</td><td>A+</td></tr> <tr><td>7</td><td>A-</td></tr> <tr><td>5</td><td>B+</td></tr> <tr><td>8</td><td>B-</td></tr> <tr><td>6</td><td>Z+</td></tr> <tr><td>9</td><td>Z-</td></tr> <tr><td>10</td><td>U+</td></tr> <tr><td>13</td><td>U-</td></tr> <tr><td>11</td><td>V+</td></tr> <tr><td>14</td><td>V-</td></tr> <tr><td>12</td><td>W+</td></tr> <tr><td>15</td><td>W-</td></tr> <tr><td>2</td><td>EP5</td></tr> <tr><td>3</td><td>EM</td></tr> <tr><td>1</td><td>PE</td></tr> </table>	4	A+	7	A-	5	B+	8	B-	6	Z+	9	Z-	10	U+	13	U-	11	V+	14	V-	12	W+	15	W-	2	EP5	3	EM	1	PE							
A+	24																																																																						
A-	12																																																																						
B+	23																																																																						
B-	11																																																																						
Z+	22																																																																						
Z-	10																																																																						
U+	21																																																																						
U-	9																																																																						
V+	20																																																																						
V-	8																																																																						
W+	19																																																																						
W-	7																																																																						
EP5	5/6/17/18																																																																						
EM	1/2/3/4																																																																						
N.C.	13																																																																						
N.C.	25																																																																						
4	A+																																																																						
7	A-																																																																						
5	B+																																																																						
8	B-																																																																						
6	Z+																																																																						
9	Z-																																																																						
10	U+																																																																						
13	U-																																																																						
11	V+																																																																						
14	V-																																																																						
12	W+																																																																						
15	W-																																																																						
2	EP5																																																																						
3	EM																																																																						
1	PE																																																																						
Screw type: UNC 4-40 (plug-in terminal block)																																																																							
Tightening torque: 0.5 - 0.6 Nm																																																																							

## 2.4 Signal sequence example

### Power-on sequence



### Power-off sequence




# 3 Commissioning

## 3.1 Commissioning

### 3.1.1 Main menu

#### Displays and settings



#### The status menu items


Menu item	Definition	Preconditions for display of normal status
<b>Normal status</b>		
8.8.8.8.8.8.	Initializing the drive (drive self-testing at power-on). "8.8.8.8.8.8." will stay for about 1 second during the process.	<ul style="list-style-type: none"> <li>No error code appears</li> <li>No power supply (24 V DC) fault</li> </ul>

Menu item	Definition	Preconditions for display of normal status
S-2	Precharging the drive (waiting for the 220 V mains power)	<ul style="list-style-type: none"> <li>No power supply (24 V DC) fault</li> <li>No alarm code appears</li> <li>No error code appears</li> </ul>
S-3	Waiting for drive enable from terminal 65 at X6	<ul style="list-style-type: none"> <li>No power supply (24 V DC or 3AC 220 - 240 V) fault</li> <li>No alarm code appears</li> </ul>
S-4	Waiting for pulse enable from terminals ENA+ and ENA- at X5	<ul style="list-style-type: none"> <li>No power supply (24 V DC or 3AC 220-240 V) fault</li> <li>No alarm code appears</li> <li>Terminal 65 has been enabled</li> </ul>
S-RUN	Drive is running properly	<ul style="list-style-type: none"> <li>No power supply (24 V DC or 3AC 220-240 V) fault</li> <li>No alarm code appears</li> <li>Terminals 65 has been enabled via an external 24 V DC power supply</li> <li>Terminals ENA+ and ENA- have been enabled</li> </ul>
<b>Alarm status</b>		
S-A01 ... S-A45	Displays an alarm code associated with a fault existent in the drive system	

**Descriptions of main keys:**

Key	Definition	Function
	Mode selection	Switch between 4 main menu items (Status, Parameter Set, Data Display and Function) or return current display to next higher-level.
	Enter	Go to next lower-level menu item or back to higher-level item, confirm value (save modified value into RAM) or cancel an alarm.






### Note

All parameter settings made in Parameter Set mode will be saved to RAM only. At next drive power-on, the settings made will be recovered to the setting prior to the last setting automatically. To save the setting permanently, you should use "Save user parameter" menu entry under "Function" main menu.

Detailed description of individual parameters can be found in Section 3.2 "Parameter list" (Page 29).



**Note**


Detailed description of individual display data can be found in Section 3.3 "Display data list" (Page 31).

**3.1.3 Setpoints from NC**

Machine Data	Designation	Unit	Axis	Setpoint	Description
31020	ENC_RESOL	PPR	X, Z (808D Turning) X, Y, Z (808D Milling)	10,000	Encoder revolution (2,500) x Multiplier (4)
31400	STEP_RESOL L	IPR	X, Z (808D Turning) X, Y, Z (808D Milling)	10,000	Steps per servo motor revolution


### 3.1.4 First commissioning

Follow the procedure below to complete the first commissioning of the drive and motor:



### 3.1.5 System commissioning

Follow the procedure to complete the system commissioning:



## 3.2 Parameter list

Par. No.	Name	Range	Default	Increment	Unit	Effective
P01	<b>Parameter write protection</b>	0 - 1	0	1	-	Immediately
	0: Sets all parameters other than P01 as read-only parameters. 1: Sets all parameters to be both readable and writable.					
	<b>P01 automatically resets to 0 after power-on!</b>					
P05	<b>Internal enable</b>	0-1	0	1	-	Immediately
	0: JOG mode can be enabled externally. 1: JOG mode can be enabled internally.					
	<b>P05 automatically resets to 0 after power-on!</b>					
P16	<b>Maximum motor current</b>	0-100	100	1	%	Power On
	This parameter specifies the maximum motor current (2 x rated motor current) of your choice.					
P20	<b>Speed loop proportional gain</b>	0.01-5.00	Depends on drive version	0.01	Nm*s/rad	Immediately
	<b>Factory defaults:</b> 4 Nm: 0.81(0.54); 6 Nm: 1.19(0.79); 7.7 Nm: 1.50(1.00); 10 Nm: 2.10(1.40)					
	<b>Note:</b> Default value varies with software version.					
	This parameter specifies the proportional gain ( $K_p$ , proportional component) of speed control loop. The bigger the value, the higher the gain and rigidity. The setting depends on specific drive and load. Generally, the bigger the load inertia, the bigger the value is to set. If however, there is no oscillation occurred in the system, you can set the value as big as possible.					
P21	<b>Speed loop integral time constant</b>	0.1-300.0	Depends on drive version	0.1	ms	Immediately
	<b>Factory defaults:</b> 4 Nm: 17.7(44.2); 6 Nm: 17.7(44.2); 7.7 Nm: 17.7(44.2); 10 Nm: 18.0(45.0)					
	<b>Note:</b> Default value varies with software version.					
	This parameter specifies the integral action time ( $T_n$ , integral component) of speed control loop. The smaller the value, the higher the gain and rigidity. The setting depends on specific drive and load.					
P26	<b>Maximum motor speed</b>	0-2200	2200	20	rpm	Power On
	Sets the maximum possible motor speed.					
P30	<b>Position loop proportional gain</b>	0.1-3.2	3.0(2.0)	0.1	1000/min	Immediately
	1. This parameter specifies the proportional gain of position loop. 2. The bigger the value, the higher both the gain and rigidity, and at the same pulse command frequency the smaller the position hysteresis. However, excessively high value setting may cause system oscillation or overshooting. 3. The setting depends on specific drive and load.					
P31	<b>Position loop feedforward gain</b>	0-100	85(0)	1	%	Immediately
	1. This parameter specifies the feedforward gain of position loop. 2. Setting the value to 100 % means position hysteresis is always 0 at any pulse command frequency. 3. Increasing the feedforward gain of position loop improves the high-speed response characteristics of the control system, but meanwhile causes the system's position loop unstable and liable to oscillation. 4. Unless very high response characteristics are necessary, set the feedforward gain of position loop to 0.					
P34	<b>Maximum following error</b>	20-999	500	1	100 pulses	Immediately

Par. No.	Name	Range	Default	Increment	Unit	Effective
	This parameter specifies the maximum possible following error. When the actual following error is larger than the setpoint, the drive sends an over-position alarm (A43)					
P36	<b>Input pulse multiplier</b>	1, 2, 4, 5, 8, 10, 16, 20, 100, 1000	1	-	-	Power On
	This parameter specifies the input pulse multiplier. For example, when P36 = 100, input frequency = 1 kHz, output frequency = 1 kHz × 100 = 100 kHz					
	<b>Note:</b> Pulse frequency setpoint = Actual pulse frequency x input pulse multiplier; This parameter is applicable only when the software version is V01.06 or later; When P36 = 100 or 1000, speed stability will decrease with higher multiplication factor.					
P38	<b>Pulse tracking enable</b>	0-1	0	1	-	Power On
	This parameter enables/disables the pulse tracking function. 0: Disables the pulse tracking function. <ul style="list-style-type: none"> <li>No matter whether the difference between the position setpoint and the position actual value is smaller than 1000 pulses or not when the drive is in "S-2", "S-3", or "S-4" state, both the two values will be set to 0 after the drive becomes "S-Run".</li> </ul> 1: Enables the pulse tracking function. <ul style="list-style-type: none"> <li>If it's detected that the difference between the position setpoint and the position actual value is smaller than or equal to 1000 pulses when the drive is in "S-2", "S-3", or "S-4" state, the motor will be aligned to the position setpoint after the drive becomes "S-Run".</li> <li>If it's detected that the difference between the position setpoint and the position actual value is greater than 1000 pulses when the drive is in "S-2", "S-3", or "S-4" state, Fault A24 is thrown out after the drive becomes "S-Run".</li> </ul>					
	<b>Note:</b> This parameter is applicable only when the software version is V01.08 or later.					
P41	<b>Brake open delay</b>	20-2000	100	10	ms	Power On
	When the drive is enabled, the drive brake will be opened after a delay which is set by P41. Drive can be enabled under the following conditions:  <b>A:</b> When the following three conditions are all met: 1. Terminal 65 (external enable) has been enabled; 2. The drive has received an enable signal from NC; 3. No alarm is detected by the drive. <b>B:</b> When the following two conditions are both met: 1. Terminal 65 (control enable) has been activated; 2. Motor operates in "JOG-RUN" mode (enabled from function menu ) <b>C:</b> When the following two conditions are both met: 1. P05 = 1 (The JOG mode can be enabled internally); 2. Motor operates in "JOG-RUN" mode (enabled from function menu )					
P42	<b>Brake close time while motor operation</b>	20-2000	100	10	ms	Power On
	When motor speed exceeds 30 rpm and the drive generates an alarm, if, within the specified brake close time (P42), actual motor speed remains bigger than brake close speed setpoint (P43), brake is closed after the specified brake close time (P42) expires.					
P43	<b>Brake close speed while motor operation</b>	20-2000	100	20	r/min	Power on

Par. No.	Name	Range	Default	Increment	Unit	Effective
	When motor speed exceeds 30 rpm and the drive generates an alarm, if, within the specified brake close time (P42), the actual motor speed becomes smaller than the P43 setpoint, brake is closed when the actual speed reaches the speed P43 sets.					
P44	<b>Drive enable time after the brake close</b>	20-2000	600	10	ms	Power on
	When motor speed is lower than 30 rpm, the drive remains enabled within the time period set by P44 after brake close.					
P46	<b>JOG speed</b>	0-2000	200	10	rpm	Immediately
	This parameter specifies the motor speed in JOG mode.					
P47	<b>Ramp-up/-down time constant</b>	0.0 – 10.0	4.0	0.1	s	Power on
	This parameter defines the time period when the motor ramps up from 0 rpm to 2,000 rpm or ramps down from 2,000 rpm to 0 rpm.					
P99	<b>Reserved for Siemens internal use only</b>					


#### Note

The default values in brackets are the second default values.

### 3.3 Display data list


Data no.	Name	Data format	Unit	Data group
D10*	Torque setpoint	Decimal	Nm	Current
D11*	Actual value of the torque	(See table below)	Nm	
D12*	Actual value of the phase current		A	
D20	Motor speed setpoint	Integer	RPM	Speed
D21	Actual motor speed		RPM	
D30	Position revolution setpoint		Motor revolutions	Position
D31	Position angle setpoint		Increments (10000/r)	
D32	Actual position revolutions		Motor revolutions	
D33	Actual position angle		Increments (10000/r)	
D34	Position deviation angle		Increments (10000/r)	
D50*	Digital input signal	Bit (See table below)	Bits in hex	I/O
D51*	Digital output signal		Bits in hex	
D80*	Firmware version	(See table below)		HW, FW
D81	Power Board rated current	Integer		
D82*	Parameter version number	(See table below)		

\* The data type of D10, D11, D12, D80, D82 is all decimal format. The display value for D50 and D51 respectively varies as the case may require.



## 4 Troubleshooting

### 4.1 LED status indicators



### Descriptions of LED status indicators

H1	H2	Description	7-segment LED display description
RDY/JOG Green LED	ERR Red LED		
Dark	Dark	No 24 V DC input or drive defect	Dark
Dark	Flash light with 1 Hz	Drive not ready	Current status
Green	Dark	Drive ready	Depends on current menu operation
Dark	Red	Drive error	Alarm code
Green	Red	Initialization	Display "8.8.8.8.8.8."
Flash light with 1 Hz	Dark	JOG mode	Display "J-run"

## 4.2 Alarms

### Overview of alarms

Alarm code	Alarm name	Description
A01	Power board ID number error	Unable to identify the power board
A02	Parameter error	Parameter validation error (CRC error, encoder type or parameter header invalid)
A03	Memory-write failure	Unable to write data to memory
A04	Control voltage error	Control voltage is lower than 3.5 V.
A05	IGBT overcurrent	IGBT is detected overcurrent.
A06	Internal chip overcurrent	Internal chip is detected overcurrent.
A07	Grounding short circuit	Grounding short circuit occurs during drive initialization
A08	Encoder UVW signals error	Signals from encoder phases U, V, W are detected all the same (all high or all low)
A09	Encoder TTL signals error	TTL pulse error
A14	Internal error	Software failure
A21	DC link voltage overvoltage	DC link voltage is higher than 405 V
A22	IT protection	IGBT current exceeds the upper limit for 300 ms
A23	DC link voltage undervoltage	DC link voltage is lower than 200 V
A24	Pulse tracking error too big	The difference between the position setpoint and the position actual value is greater than 1000 pulses (1/10 rotation).
A41	Overspeed	Actual motor speeds is higher than 2300 rpm
A42	IGBT overtemperature	IGBT becomes overheating
A43	Following error too big	Following error exceeds the limit
A44	I <sup>2</sup> t protection	Motor load exceeds nominal motor torque
A45	Emergency stop	Enable signal from Terminal 65 is lost during normal drive running

### Alarm list

Alarm code	Background	Possible Cause	Remedy	Result	Acknowledgement
A01		Power board is broken	Replace the drive with a new one	Free stop	Power on
A02		The memory is damaged due to unexpected power-off during data saving	Restore default parameters	Free stop	Power on

Alarm code	Background	Possible Cause	Remedy	Result	Acknowledgement
A03		Memory is damaged	Replace the drive with a new one	Free stop	Power on
A04		The 24 V DC supply is abnormal	Check the 24 V DC supply	Free stop	Power on
		The drive is defective	Replace the drive with a new one		
A05	This alarm may occur when the DC link is connected	<ol style="list-style-type: none"> <li>1. There is a short-circuit between terminals U, V, W and PE on the drive</li> <li>2. bad grounding</li> <li>3. motor insulation is broken</li> <li>4. the drive is broken</li> </ol>	<ol style="list-style-type: none"> <li>1. check the wiring</li> <li>2. make a correct grounding</li> <li>3. replace the motor with a new one</li> <li>4. replace the drive with a new one</li> </ol>	Free stop	Power on
	This alarm may occur when the motor is running				
A06	This alarm may occur when the DC link is connected	<ol style="list-style-type: none"> <li>1. There is a short-circuit between terminals U, V, W and PE on the drive</li> <li>2. bad grounding</li> <li>3. motor insulation is broken</li> <li>4. the drive is broken</li> </ol>	<ol style="list-style-type: none"> <li>1. check the wiring or whether the connection to U, V or W is broken</li> <li>2. make a correct grounding</li> <li>3. replace the motor with a new one</li> <li>4. replace the drive with a new one</li> </ol>	Free stop	Power on
	This alarm may occur when the motor is running				
A07	This alarm may occur when the DC link is connected	<ol style="list-style-type: none"> <li>1. IGBT module is broken</li> <li>2. There is a short-circuit between U, V or W and PE</li> </ol>	<ol style="list-style-type: none"> <li>1. replace the drive with a new one</li> <li>2. Check the wiring</li> </ol>	Free stop	Power on
	This alarm may occur when the motor is running				
A08		<ol style="list-style-type: none"> <li>1. UVW signals of the encoder are bad</li> <li>2. bad cable</li> <li>3. bad cable shielding</li> <li>4. bad wiring of the shielded ground cable</li> <li>5. there is a failure in the interface circuit of the encoder</li> </ol>	<ol style="list-style-type: none"> <li>1. replace the drive with a new one</li> <li>2. Check the interface circuit of the encoder</li> </ol>	Free stop	Power on
A09		<ol style="list-style-type: none"> <li>1. connection failure of encoder ABZ</li> <li>2. bad cable</li> <li>3. bad cable shielding</li> <li>4. bad wiring of the shielded grounded cable</li> <li>5. there is a failure in the interface circuit of the encoder</li> </ol>	<ol style="list-style-type: none"> <li>1. check the wiring of encoder cable</li> <li>2. Check the interface circuit of the encoder</li> </ol>	Free stop	Power on
A14		There is failure at the internal software	Reset by power-on	Free stop	Power on

Alarm code	Background	Possible Cause	Remedy	Result	Acknowledgement
		A short-circuit occurs to the encoder	Check the wiring of encoder		
A21	This alarm may occur when the 24 V DC supply is connected	There is a failure at the circuit board	Replace the drive with a new one	Free stop	Press the Enter key on the operator panel or terminal RST of the X6 interface
	This alarm may occur when the DC link is connected	1. the mains supply voltage is too high 2. the waveform of mains supply voltage is abnormal	Check the power supply		
	This alarm may occur when the motor is running	1. disconnection of the internal brake resistor 2. the internal brake resistor is broken	Replace the drive with a new one		
		Brake loop has no enough space	1. lower the start-stop frequency 2. minish the limit value of current 3. minish load inertia 4. use another drive and motor with higher power		
A22		The motor is mechanically blocked	Check the mechanical load	Free stop	Press the Enter key on the operator panel or terminal RST of the X6 interface
		Overload	1. lighten the load 2. use another drive and motor with bigger power		
A23		1. circuit board fails 2. fuse of the power is burnt out 3. rectifier is broken	Replace the drive with a new one	Free stop	Press the Enter key on the operator panel or terminal RST of the X6 interface
		1. low supply voltage 2. insufficient supply power capacity 3. transient power failure	Check the power supply		
A24	This alarm may occur when it's detected that the difference between the position setpoint and the position actual value is greater than 1000 pulses when the drive is in "S-2", "S-3", or "S-4" state	There is pulse inputs at the setpoint interface X5 when the drive is in "S-2", "S-3", or "S-4" state	When P38 = 1, check whether more than 1000 pulses are received at the setpoint interface X5 when the drive is in "S-2", "S-3", or "S-4" state	Free stop	Press the Enter key on the operator panel or terminal RST of the X6 interface
		There is shaft move when the drive is in "S-2", "S-3", or "S-4" state	When P38 = 1, check whether the motor shaft moves more than 1000 pulses when the drive is in "S-2", "S-3", or "S-4" state		
A41	This alarm may occur when the	Circuit board fails	Replace the drive with a new one	Emergency stop (the	Press the Enter key on the operator

Alarm code	Background	Possible Cause	Remedy	Result	Acknowledgement
	24 V DC supply is connected	The encoder fails	Replace the drive with a new one	motor will stop with the maximum energy or torque)	panel or terminal RST of the X6 interface
	This alarm may occur when the motor is running	The encoder fails	Replace the drive with a new one		
		The encoder cable is badly connected	Replace the drive with a new one		
	This alarm may occur when the motor starts running	1. terminals U, V, and W on the motor are wrongly connected 2. the encoder is wrongly wired	Check the wiring		
A42		Ambient temperature is too high	Check the ambient temperature	Emergency stop (the motor will stop with the maximum energy or torque)	Press the Enter key on the operator panel or terminal RST of the X6 interface
		The drive is overloaded	Check the drive load		
			Replace the drive with a new one		
A43	This alarm may occur when the 24 V DC supply is connected	Circuit board fails	Replace the drive with a new one	Emergency stop (the motor will stop with the maximum energy or torque)	Press the Enter key on the operator panel or terminal RST of the X6 interface
	The motor does not rotate or reversely rotates if the command pulse is input after DC-link and mains line are connected	1. terminals U, V, and W on the motor is wrongly connected 2. encoder cable is wrongly connected	Check the wiring		
		Encoder fails	Replace the motor with a new one		
		This alarm may occur when the motor is running	The maximumly-permitted following error is too small		
		The position loop gain is too small	Give more gains		
		No enough torque	Check the limit value of current		
			Reduce the load		
			Use a drive and motor with bigger power		
Low speed	Check the maximum speed limitation (refer to parameter P26)				
Command pulse frequency is too high	1. Lower the frequency 2. Check whether P36 has the right value				
A44	This alarm may occur when the 24 V DC supply is connected	Circuit board fails	Replace the drive with a new one	Emergency stop (the motor will stop with	Press the Enter key on the operator panel or terminal RST of the X6

Alarm code	Background	Possible Cause	Remedy	Result	Acknowledgement
	This alarm may occur when the DC link is connected	The rated torque is exceeded	1. check the load 2. lower the start/Stop frequency 3. use drive and motor with more power	the maximum energy or torque)	interface
		The brake is not open	Check whether the brake is open or not		
		The motor is not stable	1. modify the gain value 2. lessen load inertia		
		The encoder is wrongly wired	Check the wiring		
A45		The 65 enable signal is lost when the motor is running	Check the 65 enable terminal	Emergency stop (the motor will stop with the maximum energy or torque)	Press the Enter key on the operator panel or terminal RST of the X6 interface

#### NOTICE

##### Canceling an alarm

Alarms with alarm code < A21 can be cancelled by power-on, while alarms with alarm code ≥ A21 can be cancelled by RST terminal.

## 4.3 Errors during drive self-test

The drive module always conducts a self-test at every power-on. If any error occurs during this period, the drive screen form will show one of the following error codes:

#### Drive error list

Drive display	Description	Cause	Remedy
	Error 1	RAM damaged	Replace the drive
	Error 2	Flash damaged	Replace the drive
	Error 3	Program copy error	Replace the drive

## 4.4 Other faults

1. Brake not open
  - Description: The brake is not open when the drive is in "S-Run" state.
  - Cause: A short circuit has occurred in the brake cable.
  - Remedy: Check brake cable connection.
  
2. Axis position incorrect or axis does not move
  - Description: When status display on SINAMICS V60 is "S-Run", the axis position is incorrect or the axis does not move.
  - Cause: Pin +PLUS or -PLUS is not well connected.
  - Remedy: Check the cable connection on the pin +PLUS or -PLUS.
  
3. Axis does not move
  - Description: When status display on SINAMICS V60 is "S-4", the axis does not move even the CNC controller has sent out pulse signals.
  - Cause: Pin +ENA or -ENA is not well connected.
  - Remedy: Check the cable connection on the pin +ENA or -ENA.
  
4. Axis keeps running in a single direction
  - Description: When status display on SINAMICS V60 is "S-Run", the axis corresponding keeps running in a single direction no matter positive signals or negative signals are given.
  - Cause: Pin +DIR or -DIR is not well connected.
  - Remedy: Check the cable connection on the pin +DIR or -DIR.

## Appendix

### A.1 Order numbers

Item	Variant	Order number
SINAMICS V60 CPM60.1 drives	4 A	6SL3210-5CC14-0UA0
	6 A	6SL3210-5CC16-0UA0
	7 A	6SL3210-5CC17-0UA0
	10 A	6SL3210-5CC21-0UA0
1FL5 servo motors	4 Nm, without key and brake	1FL5060-0AC21-0AG0
	4 Nm, without key, with brake	1FL5060-0AC21-0AH0
	6 Nm, without key and brake	1FL5062-0AC21-0AG0
	6 Nm, without key, with brake	1FL5062-0AC21-0AH0
	7.7 Nm, without key and brake	1FL5064-0AC21-0AG0
	7.7 Nm, without key, with brake	1FL5064-0AC21-0AH0
	10 Nm, without key and brake	1FL5066-0AC21-0AG0
	10 Nm, without key, with brake	1FL5066-0AC21-0AH0
	4 Nm, with key, without brake	1FL5060-0AC21-0AA0
	4 Nm, with key and brake	1FL5060-0AC21-0AB0
	6 Nm, with key, without brake	1FL5062-0AC21-0AA0
	6 Nm, with key and brake	1FL5062-0AC21-0AB0
	7.7 Nm, with key, without brake	1FL5064-0AC21-0AA0

Item	Variant	Order number
	7.7 Nm, with key and brake	1FL5064-0AC21-0AB0
	10 Nm, with key, without brake	1FL5066-0AC21-0AA0
	10 Nm, with key and brake	1FL5066-0AC21-0AB0
Encoder cables (with undetachable connector housing)	3 m	6FX6002-2LE00-1AD0
	5 m	6FX6002-2LE00-1AF0
	7 m	6FX6002-2LE00-1AH0
	10 m	6FX6002-2LE00-1BA0
Power cables	3 m	6FX6002-5LE00-1AD0
	5 m	6FX6002-5LE00-1AF0
	7 m	6FX6002-5LE00-1AH0
	10 m	6FX6002-5LE00-1BA0
Brake cables	3 m	6FX6002-2BR00-1AD0
	5 m	6FX6002-2BR00-1AF0
	7 m	6FX6002-2BR00-1AH0
	10 m	6FX6002-2BR00-1BA0

## A.2 Technical support

If you have any question (any suggestion or amendment) about this product or this document, please call SIEMENS technical support or visit SIEMENS internet:

### For Chinese customers:



00 86 400 810 4288



00 86 10 6471 9991



4008104288.cn@siemens.com

### For customers outside China:



00 49 0911 895 7222



00 49 0911 895 7223



support.automation@siemens.com

For the local contact data, please refer to Contact Database:

<http://www.automation.siemens.com/mcms/aspa-db/en/service/Pages/default.aspx>

New Support Request:

<http://www.siemens.com/automation/support-request>

Internet:

<http://www.siemens.de/automation/service&support>

FAQ:

[http://www.siemens.de/automation/csi\\_en/product](http://www.siemens.de/automation/csi_en/product)

---

## **Trademarks**

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

## **Disclaimer of Liability**

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Siemens AG  
Industry Sector  
Postfach 48 48  
90026 NÜRNBERG

Controlled Power Module (CPM60.1)  
A5E03975175-002, 04/2014